

ANDERSON[®]

A Division of The Clark•Reliance Corporation

| |
|-------------------|
| Section: A500 |
| Bulletin: A500.15 |
| Date: 2/15/97 |
| Supersedes: new |

INSTALLATION, OPERATION AND MAINTENANCE INSTRUCTIONS FOR ANDERSON ACF SERIES COALESCING FILTERS

INSTALLATION INSTRUCTIONS

1. INSTALL THE FILTER SO THAT THE DIRECTION OF FLOW CORRESPONDS TO THE FLOW ARROW ON THE VESSEL AND INLET AND OUTLET MARKINGS ON THE DRAWINGS. IF NEITHER AVAILABLE, CONSULT THE CATALOG OR THE FACTORY FOR PROPER INSTALLATION.
2. PROPER DRAINAGE OF THE FILTER IS ESSENTIAL FOR PROPER OPERATION. CONNECT THE DRAIN TO A DRAIN TRAP, OR WHATEVER MECHANISM YOU INTEND TO USE IN ORDER TO REMOVE THE SEPARATED LIQUIDS FROM THE SEPARATOR. SHOULD THE TRAP OR DUMPING MECHANISM REQUIRE AN EQUALIZING LINE, OR INSTRUMENT SUPPLY GAS, THIS SHOULD BE CONNECTED TO THE VENT CONNECTION.
3. CONNECT THE FILTER BY THE STANDARD PIPING METHODS AS PRESCRIBED BY LOCAL, STATE, AND GOVERNMENT AUTHORITIES. PIPE ALL CONNECTIONS ON FIRST AND SECOND STAGES INDEPENDENTLY. GAUGE GLASS, LIQUID LEVEL CONTROLS, AND DRAINS SHOULD NEVER BE MANIFOLDED BETWEEN THE INLET (PRIMARY) AND OUTLET (SECONDARY) STAGES.
4. DO NOT OPERATE WITHOUT FIRST REMOVING THE TOP HEAD TO MAKE SURE THE ELEMENT HOLD DOWN NUTS ARE TIGHT: MIN/MAX TORQUE IS: _____ FT*LBS
5. VERIFY TOP BODY FLANGE IS SECURELY FASTENED. BUILD UP PRESSURE IN SYSTEM, CHECK ALL FIELD CONNECTIONS AND BODY FLANGE FOR LEAKS. IF LEAKS EXIST DE-PRESSURIZE SYSTEM AND REPAIR LEAK SITES BY APPROVED METHOD.
6. IF NO LEAKS ARE FOUND, CHECK TO INSURE THAT ALL INSTRUMENTS ARE READY FOR ON-LINE OPERATION. REFER TO THE SEPCIFIC OPERATION MANUAL FOR THE APPROPRIATE PIECE OF EQUIPMENT FOR PROPER ON-LINE OPERATION AND MAINTENANCE.

OPERATING INSTRUCTIONS

1. ONCE THE ANDERSON SEPARATOR IS INSTALLED, IT NEEDS NO OTHER ACTION BY THE OPERATOR. THE SEPARATOR IS COMPLETE IN ITSELF, AND WILL FUNCTION WHENEVER THERE IS FLOW THROUGH THE SEPARATOR.
2. IF POSSIBLE, AN INITIAL CHECK OF DIFFERENTIAL PRESSURE SHOULD BE MADE ACROSS THE FILTER ELEMENT FOR REFERENCE. IF SOLIDS ARE PRESENT IN THE GAS, THE COALESCER CARTRIDGE WILL GRADUALLY BECOME PLUGGED AND THE DIFFERENTIAL PRESSURE WILL INCREASE.

INSTALLATION, OPERATION AND MAINTENANCE INSTRUCTIONS

**FOR ANDERSON ACF SERIES COALESCING FILTERS
(CONTINUED)**

3. AFTER THE FILTER HAS BEEN IN SERVICE FOR A FEW HOURS, CHECK THE GAGE GLASSES IN THE TWO STAGES FOR THE AMOUNT OF CONDENSATE THAT HAS COLLECTED. JERGUSON® BRAND GAGE GLASSES ARE HIGHLY RECOMMENDED FOR PROPER LEVEL MONITORING IN THIS HIGHLY CRITICAL OPERATION. IF AUTOMATIC DRAINING DEVICES ARE NOT INSTALLED, THE CONDENSATE MUST BE REMOVED MANUALLY ON AN INTENSIVE INSPECTION SCHEDULE PER THE CYCLE LOAD REQUIREMENTS.

MAINTENANCE INSTRUCTIONS

1. THERE IS VERY LITTLE REQUIRED MAINTENANCE WITH THIS SEPARATOR, EXCEPT FOR THE PERIODIC REPLACEMENT OF THE COALESCER ELEMENT. **IMPORTANT: DO NOT BACK-FLOW THE COALESCING ELEMENT!!**
2. GENERAL REQUIREMENTS FOR COALESCER REPLACEMENT:
 - A. WHEN DIFFERENTIAL PRESSURE REACHES 7-8 PSID, OR
 - B. WHEN DIFFERENTIAL PRESSURE REACHES CUSTOMERS LIMIT, OR
 - C. ONCE A YEAR.
3. WHEN CHANGING COALESCER ELEMENTS, OPEN UP DRAIN CONNECTIONS AND BLOWDOWN / WASH OUT ANY DEBRIS. THE PRIMARY SEPARATION STAGE (LOWER) WILL HAVE THE HIGHEST CONCENTRATION OF DEBRIS AND SHOULD BE WASHED OUT FREQUENTLY.
4. USE ONLY ANDERSON SUPPLIED FACTORY WARRANTED COALESCING ELEMENTS. THE USE OF OTHER NON-FACTORY SUPPLIED ELEMENTS VOIDS ALL WARRANTIES OF THE EQUIPMENT SUPPLIED.
5. FOLLOW ALL LOCAL, STATE, AND GOVERNMENT CODES AND REGULATIONS WHEN ISOLATING AND DE-PRESSURIZING FILTER FOR MAINTENANCE.
6. IF ANY DIFFICULTIES ARE EXPERIENCED WITH THE ANDERSON ACF FILTER, PLEASE CONTACT THE FACTORY FOR THE NAME OF AN AUTHORIZED REPRESENTATIVE CLOSEST TO YOUR SITE.
6. THANK YOU FOR PURCHASING WHAT WE BELIEVE IS ONE OF THE HIGHEST QUALITY FILTERS THAT IS OFFERED IN THE MARKETPLACE TODAY. WE ARE CONSTANTLY INNOVATING TO BRING YOU THE MOST COST-EFFECTIVE SOLUTION TO YOUR SEPARATION AND FILTRATION NEEDS.

PHONE: (440) 572-1500 FAX: (440) 238-8828